



CAD files Comblift 543-2,0


File name: 543-Standard_en
Section Comblift 543 Standard type




File name: 543-Standard_planning_en
Section for planning Comblift 543 Standard type



File name: 543-Economic_en
Section Comblift 543 Economic type




File name: 543-Economic_planning_en
Section for planning Comblift 543 Economic type




CAD files Comblift 543-2,0


File name: DS-543-first-grid_en
Topview first grid



File name: DS-543-middle-grid_en
Topview middle grid




File name: DS-543-end-grid_en
Topview end grid




Example Comblift 543 with 3 grids

1 x DS-543-first-grid | 1 x DS-543-middle-grid | 1 x DS-543-end-grid



Example Comblift 543 with 6 grids



1 x DS-543-first-grid | 4 x DS-543-middle-grid | 1 x DS-543-end-grid



CAD files Comblift 543-2,6



File name: 543-26-Standard_en
Section Comblift 543-2,6 Standard type

File name: 543-26-Standard_planning_en
Section for planning Comblift 543-2,6 Standard type




File name: 543-26-Comfort_en
Section Comblift 543-2,6 Comfort type

File name: 543-26-Comfort_planning_en
Section for planning Comblift 543-2,6 Comfort type




CAD files Combilift 543-2,6


File name: DS-543-26-first-grid_en
Topview first grid



File name: DS-543-26-middle-grid_en
Topview middle grid




File name: DS-543-26-end-grid_en
Topview end grid



Example Combilift 543-2,6 with 3 grids

1 x DS-543-26-first-grid | 1 x DS-543-26-middle-grid | 1 x DS-543-26-end-grid



Example Combilift 543-2,6 with 6 grids

1 x DS-543-26-first-grid | 4 x DS-543-26-middle-grid | 1 x DS-543-26-end-grid

