


## ■ CAD files Comblift 551-2,0


### File name: 551-Standard\_en

Section Comblift 551 Standard type




### File name: 551-Standard\_planning\_en

Section for planning Comblift 551 Standard type




### File name: 551-Economic\_en

Section Comblift 551 Economic type



### File name: 551-Economic\_planning\_en


Section for planning Comblift 551 Economic type



## ■ CAD files Comblift 551-2,0


File name: 551-Comfort\_en

Section Comblift 551 Comfort type




File name: 551-Comfort\_planning\_en

Section for planning Comblift 551 Comfort type




# CAD files Combilift 551-2,0


**File name: DS-551-first-grid\_en**  
Topview first grid



**File name: DS-551-middle-grid\_en**  
Topview middle grid




**File name: DS-551-end-grid\_en**  
Topview end grid




## Example Combilift 551 with 3 grids

1 x DS-551-first-grid | 1 x DS-551-middle-grid | 1 x DS-551-end-grid



## Example Combilift 551 with 6 grids


1 x DS-551-first-grid | 4 x DS-551-middle-grid | 1 x DS-551-end-grid



## CAD files Comblift 551-2,6


File name: 551-26-Standard\_en

Section Comblift 551-2,6 Standard type




File name: 551-26-Standard\_planning\_en

Section for planning Comblift 551-2,6 Standard type




File name: 551-26-Economic\_en

Section Comblift 551-2,6 Economic type




File name: 551-26-Economic\_planning\_en

Section for planning Comblift 551-2,6 Economic type




## ■ CAD files Comblift 551-2,6

File name: 551-26-Comfort\_en  
Section Comblift 551-2,6 Comfort type




File name: 551-26-Comfort\_planning\_en  
Section for planning Comblift 551-2,6 Comfort type




# CAD files Comblift 551-2,6


File name: DS-551-26-first-grid\_en  
Topview first grid



File name: DS-551-26-middle-grid\_en  
Topview middle grid




File name: DS-551-26-end-grid\_en  
Topview end grid



## Example Comblift 551-2,6 with 3 grids

1 x DS-551-26-first-grid | 1 x DS-551-26-middle-grid | 1 x DS-551-26-end-grid



## Example Comblift 551-2,6 with 6 grids

1 x DS-551-26-first-grid | 4 x DS-551-26-middle-grid | 1 x DS-551-26-end-grid

